

R·W·BECK

FIGURE 5

FEMA Flood Zone Map

Brownsville, TX to Mexico
138 kV Transmission Line